KKE-512B

Bluetooth Keyboard Folio Stand

for new iPad and iPad 2

User Manual

XUMA™

Thank you for choosing Xuma.

Congratulations on the purchase of your new Xuma Bluetooth Keyboard Folio Stand for the new iPad and iPad 2. This USB-rechargeable keyboard features an ultraslim design and boasts fourteen media keys for maximum functionality. It pairs up with your iPad via Bluetooth and recharges with the included USB cable. The keyboard is housed in a stylish, textured folio, which you can unfold and use to prop up your iPad when you're ready to start typing.

Here are some basic instructions to get you through the setup & synchronization process.

A. Box Contents

1. Folio stand
2. Removable Bluetooth keyboard
3. USB charging cable
4. User instruction manual (this booklet)

Charging

To charge the keyboard, use the included USB charging cable to connect it to your computer's USB port (Figure 1) or to a USB AC adapter (not included). The charging light will glow when the unit is charging, and will turn off when it reaches a full charge. (Figure 2)

The charging light will blink when battery power is low.

Getting Started

1. Your Xuma Bluetooth keyboard comes with a folio that you can use as a stand for your iPad. To set it up as a stand, start by unfolding the folio so it lays flat.
2. Roll up the folio so it forms a pyramid. The pyramid functions as a stand for your iPad.
3. Gently set your iPad down so it rests against the stand (Figure 3). The stand supports both landscape (horizontal) and portrait (vertical) orientations.

Figure 1: Micro USB charging port

Figure 2: Charging light

Figure 3: Viewing position

Pairing Up the Keyboard

1. Turn on the keyboard by moving the power switch to the ON position. The pairing light will briefly glow.
2. To enter pairing mode and make your keyboard discoverable, press the pairing button. The pairing light will blink in pairing mode.
3. On your iPad, select Settings > General > Bluetooth. (Figure 4)
4. Select ON to activate the iPad's Bluetooth feature. The iPad will automatically search for available Bluetooth devices.
5. Select Bluetooth Keyboard from the list of discovered Bluetooth devices.
6. Type in the four-digit code that appears onscreen and press ENTER.



Figure 4

Once the initial setup is complete, your iPad will automatically recognize your Xuma keyboard for future use.

Shortcut Keys

The shortcut keys are shortcuts to various functions on your iPad. They are located in the top row, directly above the number keys. (Figure 5)

Figure 5: Shortcut Keys

- Home
- Brightness down
- Brightness up
- Onscreen keyboard
- Spotlight search
- Picture frame mode
- Switch keyboard language
- Press once for previous track
  Press and hold for fast rewind
- Play/pause
- Press once for next track
  Press and hold for fast forward
- Mute
- Volume down
- Volume up
- Activates and deactivates sleep mode on iPad

Sleep Mode

When the keyboard is inactive for fifteen minutes, it will enter sleep mode in order to conserve power. Press any key and wait for the keyboard to turn back on; it may take a few seconds.

Troubleshooting

Following are a few common problems that may arise during the operation of your Bluetooth wireless iPad Case, and basic troubleshooting solutions to avoid them.

Problem	Solution
The keyboard does not respond.	Make sure that the wireless keyboard is turned on, and that the battery is charged.
The wireless keyboard is not pairing up with the iPad.	Make sure that the wireless keyboard and the iPad are turned on, and that their batteries are charged. Make sure the wireless keyboard is within operating distance of the iPad (33 feet, or 10 m). Make sure the iPad's Bluetooth setting is turned on. Make sure to select Bluetooth Keyboard on the iPad's list of discovered Bluetooth devices. If there are multiple Bluetooth Keyboards in the iPad's list of discovered Bluetooth devices, make sure to select the right one.
The keyboard will not charge.	Make sure the USB cable is properly connected to the wireless keyboard and the power source. If you are using a USB AC adapter (not included), make sure that it has an output of at least one ampere-hour (1 Ah), and that it is properly plugged into the power outlet.

LIMITED ONE-YEAR WARRANTY

Xuma provides a limited warranty that this product is free from defects in materials and workmanship to the original purchaser under normal use for a period of one (1) year from the original purchase date or thirty (30) days after replacement, whichever occurs later (the "Warranty Period"). Our responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at its option, of any product which fails during normal consumer use.

To obtain warranty coverage during the Warranty Period, contact your place of purchase ("Seller") to obtain a return merchandise authorization ("RMA") number, and return to Seller the defective product along with proof of purchase and the RMA number.

This warranty does not extend to damage or failure which results from misuse, neglect, accident, alteration, abuse, improper installation or maintenance. EXCEPT AS PROVIDED HEREIN, XUMA MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This warranty provides you with specific legal rights, and you may also have additional rights which vary from state to state.

© Copyright 2012 Xuma